Date Conducted: 10 / 02 / 2019
Conducted By: Peter Skeete
Phone Number: (561) 841 - 4267

Inspection Date/Time: 11:00
Location: 100 North Congress Ave
Delray Beach, FL 33445

Vehicle Year/Make/Model ► PB0721 - 2007 Gillig 40 Foot Low Floor Bus

## **General Information General Condition** (circle one in each category) VIN: 15GGD211X71078143 Exterior Bad ExclInt 10174210 Asset No: Interior Bad 2 3 **X** 4 ExclInt Tires N/A 2 3 ExclInt Odometer: <u>584.683</u> Bad X Other Glass Bad 3 **X** ExclInt 4 cyl X 6 cyl Engine Displacement: CID HP Mechanical **DNR**<sub>X</sub> Runs Other 10.8 Liter Fuel Type: X Diesel Other

(describe "Other")TIRES NOT INCLUDED, BAD ENGINE

## **Options & Equipment** ( each box that applies)

X		X	ABS	X	Air Brakes
X	P/S		4x4		Boom/Bucket
	P/B		Power Door Locks		Crane
	P/W		Power Seats		Dump Bed
X	A/T		Sunroof		Tank Bed
	Manual Transmission ( forward speeds)	X	Tilt Steering		Lightbar/beacon
	AM/FM Radio	X	Tinted Windows		Power Liftgate
	CD Player				Tool Box
	Cruise Control				Trailer Hitch
	Airbags (circle one) 1 2 3 4				Utility Bed
	Performance Package:				Winch

Key					
4X4	4-Wheel Drive	CID	Cubic Inch Displacement	P/B	Power Brakes
ABS	Antilock Braking System	CNG	Compressed Natural Gas	P/S	Power Steering
A/C	Air Conditioner	DNR	Does Not Run	P/W	Power Windows
A/T	Automatic Transmission	HP	Horsepower	VIN	Vehicle Identification Number

In order to show your vehicles and equipment at their best, use the following chart and descriptions as a guide for preferred camera angles, lighting conditions, and background.

- Take the photos with a high-resolution digital camera (a minimum of 3 mega pixels is recommended).
- 2) Take the photo in an area that is well lighted, but not in a glare, and position yourself so that the sun or artificial light source does not cast your shadow into the picture.
- 3) Make sure the vehicle is washed and all logo decals have been removed with automotive adhesive remover (3M or similar). If primer must be used, select a primer color that closely matches the vehicle. If possible, pressure wash off-road equipment to remove grease and caked mud caught in treads, tracks and body panels. Make sure that truck beds are free of accumulated trash.
- Select an area with a neutral background; avoid clutter showing up behind the vehicle. Shrubbery generally makes a good backdrop.
- 5) The preferred camera locations for common vehicles are the right or left front corners of the vehicle, at approximately a 40 degree angle from straight-on, standing 8-10 feet back from the vehicle, and holding the camera at just above rooftop level (except for very tall equipment). By pointing the camera about one-third of the distance down the right or left side of the vehicle, the entire vehicle should be in the photo frame. Under these conditions, the vehicle will be well displayed and you will avoid "fish-eye" distortions of shooting directly at the leading edge (the front edge of the front fender).

